

GasAlertMicro 5 IR

Five-Gas Detector

CO₂ (IR), H₂S, CO, O₂, SO₂, PH₃, NH₃, NO₂, HCN, Cl₂, ClO₂, O₃, and CO



GasAlertMicro 5 IR portable gas detector simultaneously monitors up to five atmospheric hazards including carbon dioxide, oxygen (O₂), combustible gas (%LEL), and a wide selection of toxic gases. Compact and lightweight, GasAlertMicro 5 IR activates audible, visual and vibrating alarms in the event of low, high, TWA or STEL alarm condition.

Features:

- 0-5% vol (0-50,000 ppm) measurement of carbon dioxide
- Integral concussion-proof enclosure for the most demanding environments
- Continuous LCD shows simultaneous gas concentrations up to five gases
- Two power options: three AA alkaline batteries or rechargeable battery pack
- Simple automatic calibration procedure; compatible with BW's MicroDock II system
- Provides 95 dB alarm tone, two bright wide-angle LEDs and internal vibrating alarm for high noise areas
- Multi-language support in English, French, German and Portuguese
- Full function self-test of sensor, battery and circuitry and audible/visual alarms
- Two year warranty including sensors (1 year NH₃)

Packaging Contents:

Standard Versions: Complete with monitor and sensor (as specified), sensor compartment cover for diffusion operation, calibration adaptor and hose, quick reference guide and documentation CD, integral concussion-proof boot, and alkaline batteries.

Confined Space Kits: Includes standard version contents plus foam lined carrying case for instrument and accessories, calibration cylinder(s) of calibration gas required for sensors installed, LPM/1.0 LPM calibration regulator (male) and tubing.

ThermoFisher
SCIENTIFIC

For customer service, call 1300-735-295
Email: InfoEnviroAU@thermofisher.com
Visit us online: www.thermofisher.com.au